#### DEPARTMENT OF CIVIL AND ENVIRONMENTAL ENGINEERING

ENVIRONMENTAL ENGINEERING LABORATORY

#### LAB 1

### METAL RECOVERY FROM MUNICIPAL SLUDGE

Jacob Sigman CE-344 9/29/22

The Cooper Union for the Advancement of Science and Art 41 Cooper Square New York, NY 10003

# Contents

Li	st of Tables	2
Li	st of Figures	2
1	Purpose of the Experiment	3
2	Procedure           2.1 Freeze/Thaw            2.2 Acidification            2.3 Centrifugation	4 4 4 4
3	Data and Results3.1 Acidification3.2 Centrifugation	
4	Sample Calculations 4.1 Percentages in Reductions 4.2 Normalization	11 11 11 11
5	Discussion           5.1 Theory	12 12 12
6	Conclusions	13
7	Questions	14
8	References	15

# List of Tables

Table 1: Acidification of Sulfuric Acid Table 2: Acidification of Nitric Acid Table 3: Acidification of Acetic Acid Table 4: Centrifugation of Group A Table 5: Centrifugation of Group B Table 6: Centrifugation of Group C Table 7: Centrifugation of Group D	5 6 6 7 8 9
List of Figures	
Figure 1: Percent Solids of Sludge	5
Figure 2: Titration Curve of Sulfuric Acid	5
Figure 3: Titration Curve of Nitric Acid	6
Figure 4: Titration Curve of Acetic Acid	6
Figure 5: Percent Removal vs. Time (Group A)	7
Figure 6: Concentration vs. Time (Group A)	7
Figure 7: Percent Removal vs. Time (Group B)	8
Figure 8: Concentration vs. Time (Group B)	8
Figure 9: Percent Removal vs. Time (Group C)	9
Figure 10: Concentration vs. Time (Group C)	9
	10
	10

## 1 Purpose of the Experiment

The purpose of this experiment is to determine the best method of recovering metal from sludge. The first goal is to determine the best method for separating water from sludge. The three methods to be analyzed are freeze/thaw, acidification, and centrifugation. The second goal is to compare the titration curves of various acid samples to determine which acid is the most efficient in lowering the pH of sludge. The third goal is to observe mixing times for samples with varying acids and levels of pH and determine the optimal mixing time and acid for removing lead. This experiment will provide all necessary and optimal aspects of recovering metals from sludge.

### 2 Procedure

### 2.1 Freeze/Thaw

The separation of water from sludge is done in three ways: freeze/thaw, acidification, and centrifugation. The original water sample used contains 2% solid and 98% water, as seen in *Figure 1*. After each process, the percentages of solid and water will be recalculated. In the freeze/thaw process, the solids are removed by freezing the sample. As the water freezes, the solids will separate from the water since water has a lower freezing point. As the solution thaws, since water has a higher melting point, the water will melt first, and will be left with substantially less solids remaining.

#### 2.2 Acidification


In the acidification process, three different acids are used from three different labeled beakers. The three acids are sulfuric acid, nitric acid, and acetic acid. The acid is titrated into each beaker, and at various levels of concentration, the pH is recorded. Acid is added until the sample reached a pH of approximately 1.5 or if the normalization is too high to continue.

### 2.3 Centrifugation

In the centrifugation process, four groups are analyzed. Group A uses sulfuric acid with a pH of 1.5 at various mixing times. Group B uses sulfuric acid with a pH of 2 at various mixing times. Group C uses nitric acid with a pH of 1.5 at various mixing times. Group D uses sulfuric acid with a mixing time of six hours with various pH levels. These four groups are centrifuged and the percent removal of lead is recorded.

### 3 Data and Results

Figure 1: Percent Solids of Sludge



#### 3.1 Acidification

Table 1: Acidification of Sulfuric Acid




Table 2: Acidification of Nitric Acid

 $\underline{\text{Beaker Used:}} \quad 10\text{C} \quad \underline{\text{Solid Volume:}} \quad 95\text{ mL} \quad \underline{\text{Total Volume:}} \quad 125\text{ mL}$ 


Figure 3: Titration Curve of Nitric Acid

10
9
8
7
6
5
4
3
2
1
0
0
0.2
0.4
0.6
0.8
1
1.2
1.4
1.6
1.8
mL acid/L

m mL~acid/L	pH	${f N}$
0	7.1	0
0.13	7	0.1
0.235	7	0.19
0.385	6.95	0.31
0.525	6.85	0.42
0.715	6.75	0.57
0.915	6.5	0.73
1.115	6.3	0.89
1.465	2.2	1.17
1.565	1.9	1.25
1.665	1.75	1.33
1.765	1.6	1.41
1.865	1.45	1.49

Table 3: Acidification of Acetic Acid

Beaker Used: 11C Solid Volume: 75 mL Total Volume: 110 mL



m mL~acid/L	pH	N
0	7.6	0
0.35	6.6	0.32
0.7	5.8	0.64
1	5.1	0.91
1.25	4.9	1.14
1.65	4.5	1.5
2.2	4.3	2
2.7	4.2	2.45
3.7	4	3.36
5.7	3.8	5.18
7.7	3.6	7

## 3.2 Centrifugation

Table 4: Centrifugation of Group A

pH: 1.5 Acid: Sulfuric

Beaker	Mixing Time (hours)	Concentration (mg/L)	Percent Removed
F-SL	2	292	78%
F-SN		405	1070
B-SL	10	277	50.1%
B-SN		220	50.170
Z-SL	13	169	51.8%
Z-SN		150	91.070
W-SL	17	429	50.1%
W-SN		141	50.170
W-SL DUP	17	579	54.6%
W-SN DUP		232	94.070
H-SL	20	780	83.8%
H-SN		1125	O <b>3.</b> O70




Table 5: Centrifugation of Group B

pH: 2 <u>Acid:</u> Sulfuric

Beaker	Mixing Time (hours)	Concentration (mg/L)	Percent Removed
C-SL	10	940	51.6%
C-SN		106	31.070
N-SL	13	406	72.5%
N-SN		1080	12.970
T-SL	17	614	60.2%
T-SN		128	00.270
T-SL DUP	17	831	53.4%
T-SN DUP		128	55.470
G-SL	20	1200	42.8%
G-SN	20	98.3	42.070
H-SL	20	780	83.8%
H-SN	20	1125	03.070




Table 6: Centrifugation of Group C

pH: 1.5 Acid: Nitric

Beaker	Mixing Time (hours)	Concentration (mg/L)	Percent Removed
X-SL	17	584	64.1%
X-SN	11	116	04.170
X-SL DUP	17	677	64.8%
X-SN DUP	11	139	04.070
Q-SL	24	315	75%
Q-SN	24	269	1970
P-SL	6	469	14.7%
P-SN	O	180	14.170
A-SL	10	970	57.9%
A-SN	10	135	01.370
K-SL	13	855	55.3%
K-SN	10	298	00.070
S-SL DUP	13	793	86.3%
K-SN DUP		1500	00.970
S-SL	17	376	46.5%
S-SN		157	±0.070
S-SL DUP	17	564	59.1&
S-SN DUP	413	55.1&	






Table 7: Centrifugation of Group D

Mixing Time: 6 hours Acid: Sulfuric

Beaker	pН	Concentration (mg/L)	Percent Removed
25-SL	1.5	840	42.3%
25-SN	1.0	80.6	42.9/0
21-SL	2	1460	35%
21-SN	2	122	3370
20-SL	2.5	1160	32.4%
20-SN	2.0	104	92.470
19-SL	3	1350	28.8%
19-SN		86.1	20.070
18-SL	3.5	969	26.5%
18-SN	5.5	163	20.570





# 4 Sample Calculations

### 4.1 Percentages in Reductions

$$\label{eq:Freeze} \begin{split} \%_{\rm Freeze} &= \frac{V_{\rm Solid}}{V_{\rm Total}} \times 100 \\ {\rm Sample \ Calculation:} \ \ \%_{\rm Freeze} &= \frac{10 \ \rm mL}{100 \ \rm mL} \times 100 = 10\% \\ \%_{\rm Centrifuge} &= \frac{V_{\rm Centrate}}{V_{\rm Centrate} + V_{\rm Sludge}} \times 100 \\ {\rm Sample \ Calculation:} \ \ &= \frac{25 \ \rm mL}{25 \ \rm mL + 75 \ mL} \times 100 = 25\% \end{split}$$

### 4.2 Normalization

$$N = \frac{V_{\rm Acid}}{V_{\rm Total}} \times 100$$
 Sample Calculation: 
$$N = \frac{0.1~{\rm mL/L} \times 100~{\rm mL}}{155~{\rm mL}} \times 100 = 14.9\%$$

### 4.3 Relative Proportions

$$\label{eq:SN} \begin{split} \%_{\rm SN} &= \frac{\rm Concentration_{\rm SN}}{\rm Concentration_{\rm SN} + Concentration_{\rm SL}} \times 100 \\ \\ {\rm Sample \ Calculation: \ } \%_{\rm SN} &= \frac{10 \ \rm mg/L}{10 \ \rm mg/L + 40 \ \rm mg/L} \times 100 = 20\% \\ \\ \%_{\rm SL} &= \frac{\rm Concentration_{\rm SL}}{\rm Concentration_{\rm SN} + Concentration_{\rm SL}}} \times 100 \\ \\ {\rm Sample \ Calculation: \ } \%_{\rm SL} &= \frac{40 \ \rm mg/L}{10 \ \rm mg/L + 40 \ mg/L} \times 100 = 80\% \end{split}$$

### 5 Discussion

### 5.1 Theory

This experiment determines the percentage of lead removed from a municipal wastewater sample. This metric is crucial to public health since lead is one of seven toxic metals that are encountered in municipal wastewater. The encounter of these metals is disconcerting, but important, especially since they have effects that can devastate various species. After this metal is found, it can be treated in a wastewater facility. It's very important to treat wastewater as these metals will remain in the wastewater otherwise. Processes used to treat wastewater include reduction, conditioning, and dewatering.

Up to this point in the course, the importance of chemical and biological processes were emphasized. Both types of processes were crucial to this experiment. Acidification involves the chemical process of titration. The water is separated from the chemicals and the solids are digested. Freeze/thaw, acidification, and centrifugation are all chemical processes crucial to determining the percentage of lead removed from municipal sludge.

Overall, the three processes analyzed in this experiment are crucial to wastewater treatment facilities today. Today, America has more than 16,000 publicly-owned wastewater treatment facilities. All methods used in this experiment are used in every single one of those facilities, showing why these processes are crucial to the lives of every American.

#### 5.2 Experimental

As shown in Figure 1, the municipal sludge went through three different processes. The first of the three was freeze/thaw. Originally, the sludge contained 98% water and 2% solids. After the freeze/thaw process, 65% of the supernatant was poured off, which contained 99.6% water and 0.4% solids. The sludge sample that remained contained 94.9% water and 5.1% solids. The next process was acidification. After the acidification process, 55% of the supernatant was poured off, which contained 96.4% water and 3.6% solids. The sludge sample that remained contained 91.7% water and 8.3% solids. The next and final process was centrifugation. After the centrifugation process, 75% of the supernatant was poured off, which contained 76% water and 24% solids. The final remaining sludge was 3.9% of the original sample, which can be disposed of safely following neutralization.

The next component of the experiment is acidification. Three acids were used to acidify the sludge sample: sulfuric acid, nitric acid, and acetic acid. The primary objective is to determine what acids are successful in reducing the pH of the sludge sample to 1.5. It's very important to lower the pH of municipal sludge as it makes the metals easier to be removed. The sulfuric acid was able to reduce the pH from 7.7 to 1.6 and the nitric acid was able to reduce the pH from 7.1 to 1.45. However, the acetic acid was unsuccessful in lowering the pH. The normalization became too high and the lowest the pH was throughout the titration was 3.6. It has been determined that acetic acid is not a candidate for the acidification process.

The final component of the experiment is centrifugation. There were four groups analyzed. Group A had the highest percentage removal of lead of 83.8% at a mixing time of 20 hours with sulfuric acid with a pH of 1.5. Group D had the highest percentage removal of lead of 42.3% at a mixing time of 6 hours with sulfuric acid with a pH of 1.5. From these results it is seen that a pH of 1.5 is most effective in the removal of lead.

#### 6 Conclusions

Following the treatment of the sludge, the sludge must be neutralized, since it has a pH of 1.5 and can harm the environment. The supernatant must also follow a similar treatment process. Neutralization allows for hte pH of any solution to be brought up to the pH of water (approximately 7) by titrating it with a basic chemical.

It has been determined from the experiment that the three processes of freeze/thaw, acidification, and centrifugation are all effective methods of treating municipal sludge. The freeze/thaw process allowed for 65% of the supernatant to be poured off, the acidification process allowed for 55% of the supernatant to be poured off, and the centrifugation process allowed for 75% of the supernatant to be poured off. 3.9% of the original sample remained and was made of 76% water and 24% solids.

It was shown in the acidification data that sulfuric acid and nitric acid are effective in reducing the pH of sludge to 1.5. acetic acid is not effective in doing so.

It was shown in the centrifugation data that the most effective method of removing lead was in Group A, with a mixing time of 20 hours and sulfuric acid with a pH of 1.5. It is also shown in Group D that 1.5 is an effective pH in removing lead. Using the three processes of freeze/thaw, acidification with either sulfuric or nitric acid, and centrifugation with a 1.5 pH sample of sulfuric acid are effective in removing metals from municipal sludge.

# 7 Questions

1. Differentiate between and list systems of sludge management and ultimate sludge disposal.

Sludge management involves removing potentially reusable and recyclable materials from processed sludge. The systems include dewatering, digestion, and thickening. Ultimate sludge disposal involves discharging sludge that has already been treated. The systems include incineration, landfilling, and recycling.

2. List all heavy metals that may be encountered in an aerobically digested municipal sludge and explain briefly why they are of concern and need to be removed to a larger or lesser extent.

The metals that may be encountered in anaerobically digested municipal sludge are Cadmium, Chromium, Copper, Mercury, Nickel, lead, and Zinc. These metals must be removed as they are harmful to humans if ingested. There are many affects, such as nausea, vomiting, and stomach pain. It also increases the risk of cancer.

3. Assume that you have a 1% by weight solution of a chemical. How do you prepare a 100 mg/L solution of this using distilled water and a 100-mL graduated cylinder? If you add 1 mL of this latter solution to a beaker with 200 mL of sample, what would the concentration of the chemical be, assuming there is not a trace of this chemical in the sample?

$$1\% = 10000 \text{ mg/L} = 10 \text{ mg/mL}$$

To prepare a 100 mg/L solution, add 1 mL of solution to a 100 mL beaker of distilled water.

$$\frac{1 \text{ mL}}{200 \text{ mL}} \times \frac{100 \text{ mL}}{1 \text{ L}} = \boxed{0.5 \text{ mg/L}}$$

4. Say that you mix 100 mL of a 0.02% solution of a chemical with 50 mL of a 500 mg/L solution of the same chemical. How many mL of the final solution do you need to add in 1 L of distilled water in order to produce a concentration of 1.5 mg/L?

$$\begin{split} 0.02\% \times 100 \text{ mL} \times 10 \text{ mg/mL} + 50 \text{ mL} \times 500 \text{ mg/L} \times \frac{1 \text{ L}}{1000 \text{ mL}} &= 45 \text{ mg} \\ \frac{45 \text{ mg}}{150 \text{ mL}} &= 0.3 \text{ mg/mL} = 300 \text{ mg/L} \\ \frac{1.5 \text{ mg/L}}{300 \text{ mg/L}} \times 1000 \text{ mL} &= \boxed{5 \text{ mL}} \end{split}$$

5. You need to prepare a series of chlorine concentrations in 200-mL beakers of water samples to study the chlorine demand. What you have available is a bottle of commercial CLOROX (5.25% by weight chlorine content) and several 100-mL graduated cylinders. To reduce the error, you want to make consecutive 100X or less dilutions, so that the last prepared solution will contain 1 mg/mL of chlorine. Describe the procedure and show your calculations.

$$0.0525 \times x$$
 g CLOROX ÷ 100 mL H<sub>2</sub>O = 1 mg/mL 
$$x = 1904 \text{ mg CLOROX}$$

1904 mg CLOROX is needed to obtain a 1 mg/mL solution of chlorine. Add 1.9 mg of CLOROX to a 100 mL beaker of distilled water.

### 8 References

- 1. McCarthy, P., and Sawyer, C. N., 1981, <u>Chemistry for Environmental Engineers and Scientists</u>, 4th Ed., pp. 244-45, McGraw-Hill Book Company, New York, N.Y.
- 2. Jones, J., Brown, K., and Hirsch, R., 1985, "The Role of Phosphorus in Lake Eutrophication in New South Wales", Water Research <u>22</u> (2) 142.
- 3. Prof. C. Yapijakis, Lecture Notes, CE-344: The Cooper Union School of Engineering.
- 4. Adler, R.J., Jones, K.F., and Pappas, E.H. (1987). "Sludge Disposal by Use of Pyrolysis", J. Wat. Poll. Control Fed.,  $\underline{58}$ , 6, pp. 3-12.